




WF Watch App Instructions ([Website](#))


First Launch:

Step 1: Log in

Use your WeatherFlow account credentials from your [Life Style App](#) to log in:



Then



Then



[How to find stored passwords on Mac or Safari](#)

[How to find stored passwords on Chrome](#)

Step 2: Initial Settings

Select your measurement choices in the settings screen:




Then




Step 3: Setup WaterLock (optional)

Press the green water drop button on the bottom left of the main screen:




1. Tap
2. Select
3. Scroll and Tap
4. Select
5. Scroll and Tap


As shown here:




Then



Then



6. Close and reopen the app ([How to Close an App](#))



Subsequent Launches:


Logging In:

You should automatically be logged since the app securely stores your credentials in the keychain. It's possible that you've been logged out by Weatherflow. If so, follow the instructions for logging in above.

App Navigation


The main screen with the compass and wind speed is a scrollable list of the weather stations (spots) that have been recorded in your Favorites Profiles in your WeatherFlow app or web site.

The map and chart views are station specific. Scroll to the station of choice and the other views change to reflect data from the selected station.



Other Views

Watch Loses Connection (Wi-Fi or Cellular)



Viewing a Pro station that has no wind speed - You've been logged out by WeatherFlow

You either don't have a Pro level or higher subscription, or you've been logged out by WeatherFlow's server.

This can happen if WeatherFlow detects that you've logged in from different devices.

